

AXAGON

INSTRUCTIONS FOR USE

(original)
revision 1.0



CLONE MASTER DOCK USB-C 5Gbps for 2.5"/3.5" SATA SSD/HDD

CZ	Návod k použití (use (original))	NOR	Bruksanvisning (oversettelse)
DK	Návod k použití (original)	PL	Instrukcja użycia (tłumaczenie)
DE	Gebrauchsanweisungen (Übersetzung)	PT	Instruções de utilização (tradução)
DK	Gebrauchsanweisungen (oversættelse)	RO	Instrucţiuni pentru utilizare (traducere)
ES	Instrucciones de uso (traducción)	SK	Návod na použitie (preklad)
EST	Kasutusjuhend (tõlge)	SL	Navodila za uporabo (prevod)
FIN	Käyttöohjeet (käännös)	SRB	Upute za upotrebu (prevod)
FR	Instructions d'utilisation (traduction)	SV	Användningsinstruktioner (översättning)
GR	Οδηγίες χρήσης (απόδοση)	TR	Kullanım talimatları (tercüme)
HR	Upute za korištenje (prevod)	UA	Інструкція по застосуванню (переклад)
HU	Felhasználói kézikönyv (fordítás)	ALB	Udhëzime për përdorim (përkthim)
LT	Naudojimo instrukcija (vertimas)	BOS	Uputstvo za upotrebu (prevod)
LV	Naudojimo instrukcija (tulkojums)	CN	使用说明 (翻译)
NL	Gebruiksaanwijzing (vertaling)	ARA	أدلة الاستخدام (ترجمة)

PRODUCT SUPPORT LINK

<http://axagon.eu/produktu/adsa-sc#supportLinkGoal>

- ENG** USB docking station
- CZ** USB dokovací stanice
- DE** USB-Dockingstation
- DK** USB-dockingstation
- ESP** Estación de acoplamiento USB
- EST** USB dokkimisjaam
- FIN** USB -telakointiasema
- FR** Station d'accueil USB
- GR** Σταθμός σύνδεσης USB
- HR** USB priključna stanica
- HU** USB dokkolóállomás
- IT** Stazione di docking USB
- LT** USB prijungimo stotis
- LV** USB dokstacija
- NL** USB-dockingstation

- NOR** USB-dokkingstasjon
- PL** Stacja dokująca USB
- PT** Estação de acoplamento USB
- RO** Stație de andocare USB
- SK** USB dokovacia stanica
- SLO** USB priključna postaja
- SRB** USB priključna stanica
- SWE** USB-dockningsstation
- TR** USB yerleştirme istasyonu
- UA** Док-станція USB
- ALB** Station ankorimi USB
- BG** USB докинг станция
- BOS** USB priključna stanica
- CN** 扩展坞
- ARA** محطة إرساء USB

© 2025 AXAGON
Výrobce / Manufacturer: RealQ s.r.o., - Železná 5, 619 00 Brno, Czech Republic
All rights reserved. All text and pictorial materials contained in this document
are protected by Copyright Act.
All marks indicated here are the registered trademarks of their appropriate owners.
Specifications are subject to change without prior notice.
Made in China for AXAGON.

FCC CE RoHS

[illegible][illegible][illegible][illegible][illegible][illegible][illegible]

连接电脑
将硬盘插入插槽。
连接辅助电源。
开启电源。
将扩展坞连接到电脑的 USB 接口。
按下背面的 ON/OFF 开关打开扩展坞。
将进行自动安装。
不需要外部驱动程序。
在“磁盘管理”中初始化并格式化新硬盘 (见图 3)。

克隆

目标磁盘的容量必须等于或大于源磁盘的容量。
将源硬盘插入“Source”插槽，将目标硬盘插入“Target”插槽。
将随附的 AC/DC 适配器连接到扩展坞并接入电源。
不要将扩展坞连接到电脑的 USB 接口。
使用 ON/OFF 按钮开启扩展坞，等待 10 秒。
按住克隆按钮约 3 秒，直到所有 25% - 100% 的 LED 灯开始闪烁。
克隆过程通过 4 个 LED 指示灯显示 (25% 到 100%)，克隆完成后所有灯常亮。

信息

如果目标硬盘 (Target) 大于源硬盘 (Source)，多余的空间将保持未分配状态
未分配的空间可以在 Windows 的磁盘管理中进行管理。
在 Windows 中，可以在磁盘管理器中管理未分配空间。
克隆后，两个硬盘具有相同的 ID。如果同时连接到电脑，Windows 会禁用其中一个硬盘。
被禁用的硬盘可以在 Windows 磁盘管理中切换为在线状态。

الإضاءة بجهاز الكمبيوتر

أدخل القرص (أو الأقراص) في الفتحة ،
قم بتوصيل مصدر الطاقة الإضافي ،
قم بتشغيل الكمبيوتر ، ثم محطة الإضاءة USB بجهاز الكمبيوتر .
قم بتشغيل فاعلة التحويل باستمداً من التشغيل/الإيقاف المموج في الحلف ،
سيتم إدراج التثبيت التلقائي ، لا توجد برامج تشغيل خارجية مطلوبة .
قم بتوصيل القرص (أو الأقراص) الجديد وتنشيطه في إدارة الأقراص (انظر الصورة 3) .

الاستنساخ

يجب أن تكون نسخة القرص الوجهة مساوية أو أكبر من نسخة القرص المصدر .
أدخل القرص المصدر في فتحة "Source" ، والقرص الهدف في فتحة "Target" .
لا يتم توصيل محول التيار المتردد ، التسمك المستقر ضروري لمحاكاة الإضاءة ومحاكاة الكهزلاء .
لا يتم توصيل المحول USB بجهاز الكمبيوتر .
قم بتشغيل الفاعلة باستمداً من التشغيل/الإيقاف وانتظر لمدة 10 ثوان .
اضغط على زر الاستنساخ لمدة 3 ثوان تقريباً حتى تبدأ مؤشرات LED تحمل علامة 25% - 100% في الوميض .
تستغرق 4 دقائق LED إضاءة LED إلى تقديم عملية الاستنساخ (من 25% إلى 100%) . وعند الانتهاء تظل جميعها مضاءة بشكل دائم .

معلومات

إذا كان القرص المصدر أكبر من القرص الوجهة ، فسيظل المساحة المتبقية غير مخصصة .
يمكن إدراج المساحة غير المخصصة في إدارة الأقراص Windows .
بعد الاستنساخ ، سيكون لدى 32 القرصتين نفس المعرف ، إذا تم توصيلهما في نفس الفتحة بجهاز الكمبيوتر ،
سيؤدي نظام Windows إلى إيقاف أحد القرصين .
يمكن إعداد تشغيل القرص المعطل إلى الوضع متصل عبر إدارة الأقراص Windows .

1. CONNECTING TO A PC

A Insert disk
HDD A

B Insert disk
HDD B

C Connect USB and power

D Turn on the docking station

2. CLONE FUNCTION

A Insert disk HDD A (Source)


B Insert disk HDD B (Target)

The diagram shows a device with a top-loading drive and a front-loading drive. A 'Source disk' is being inserted into the top drive, indicated by an arrow labeled 'A'. A 'Target disk' is being inserted into the front drive, indicated by an arrow labeled 'B'. The device has a progress bar with labels 'HDD A', 'PROGRESS', and 'HDD B', and a 'CLONE' button.

C Connect power only (do not plug USB PC port)
D Turn on the docking station and wait **10 sec.**

E Press the clone button for **5 sec.** LEDs starts blinking
F Wait for permanent lighting of all LEDs
 ...duplication completed

3. INITIALIZE THE NEW DISK AND FORMAT IT IN DISK MANAGEMENT



* Disk 2
Unknown
3726.02 GB
Not Initialized


3726.02 GB
Unallocated

Initialize Disk
Offline
Properties
Help

■ Unallocated ■ Primary partition

printscreen ENG W11

SAFE DISCONNECTION OF EXTERNAL DEVICE



Safely Remove Hardware and Eject Media

Bluetooth, Drive with checkmark, Removable drive, Folder

▼ ENG [Network Icon] [Volume Icon] [Battery Icon] 11:35
21/11/2023 [Notification Bell]

printscreen ENG W11

The diagram illustrates the internal layout of the Axagon device, which is a rectangular unit with rounded corners. Inside, there are two horizontal slots labeled 'HDD A' and 'HDD B'. Below these slots, the brand name 'AXAGON' is printed. To the left of the device, there are two circular ports: the top one is labeled '2x SATA 6G slot' and the bottom one is labeled '2.5" HDD/SSD slot'. To the right of the device, there is a 'USB-C 5Gbps connection to a computer' port. Below the device, there are two circular icons: the left one is labeled '2.5" SSD/HDD' and the right one is labeled '3.5" HDD'. At the bottom of the diagram, there is a section titled 'ADVANCED LED INDICATION' which lists various status indicators and their meanings.

AXAGON

2x SATA 6G slot
2.5" HDD/SSD slot
3.5" HDD slot
All disk capacities

USB-C 5Gbps connection to a computer

2.5" SSD/HDD 3.5" HDD

ADVANCED LED INDICATION

- o POWER - green | OFF – INACTIVE | ON – ACTIVE
- o HDD A - blue | DISK A CONNECTED | FLASHING – DATA TRANSFER
- o HDD B - blue | DISK B CONNECTED | FLASHING – DATA TRANSFER
- o 25% - green | FLASHING – CLONNING IN PROGRESS 0 - 25% / ON – 25% CLONNING COMPLETE
- o 50% - red | FLASHING – CLONNING IN PROGRESS 25 - 50% / ON – 50% CLONNING COMPLETE
- o 75% - yellow | FLASHING – CLONNING IN PROGRESS 50 - 75% / ON – 75% CLONNING COMPLETE
- o 100% - orange FLASHING – CLONNING IN PROGRESS 75 - 100% / ON – 100% CLONNING COMPLETE

The diagram illustrates the front and rear views of the Dock Station. The front view shows a central circular port labeled "CLONE" and a "CLONE button" below it. Above the port is a power indicator with a "POWER" label and a scale from 0% to 100% in 20% increments. The top of the device is labeled "Aluminum body". The rear view shows a "USB 5Gbps" port, a "DC 12V" port with a "12V Power Adapter" icon and text below it, and an "ON/OFF" button. A "12V Power Adapter" icon is also shown separately with the text "DC in 12V-2.5A Use bundled power adapter 100-240V / 12V-2.5A." Below the rear view, a "PACKAGE CONTAINS:" list includes "Dock station · power adapter", "USB-A to USB-C cable 80 cm · multilingual quick guide", and "OS SUPPORTED" with a list of operating systems: "Windows · macOS · iPadOS · iOS", "Linux · Chrome OS · Android".

Front View Labels:

- Aluminum body
- CLONE
- CLONE button
- POWER
- 0% 20% 40% 60% 80% 100%

Rear View Labels:

- ON/OFF button
- ON/OFF
- DC 12V
- USB 5Gbps

12V Power Adapter

DC in 12V-2.5A
Use bundled power adapter
100-240V / 12V-2.5A.

PACKAGE CONTAINS:

- Dock station · power adapter
- USB-A to USB-C cable 80 cm · multilingual quick guide

OS SUPPORTED

- Windows · macOS · iPadOS · iOS
- Linux · Chrome OS · Android

