



## Firmware update of AXAGON external box

After downloading the archive, extract the files e.g. to the desktop, and run the firmware update utility called "**FwUpdateTool.exe**".


After launching, point the program to the update file using the **Load File** button.




Select the file located in the same folder named "**JMS583\_00\_02.01.04\_Bus Power**" and confirm the selection with the "**Open**" button.




Start the update process with the "Run" button.



During the update process, never disconnect the external box until the update is complete.



Completion of the update is shown by a message which is confirmed by pressing the "OK" button.



Then disconnect and reconnect the external box to check that the update was successful.

