

AXAGON

INSTRUCTIONS FOR USE

(original)
revision 1.0

HMC-5HL



SUPERSPEED USB-C HUB with HDMI • GLAN • PD • 2 USB-A

ENG	Instructions for use (original)	NL	Instructies voor gebruik (vertaling)
CZ	Návod k použití (originál)	PL	Instrukcja użycia (tłumaczenie)
DE	Gebrauchsanweisungen (Übersetzung)	PT	Instruções de utilização (tradução)
DK	Brugsanvisning (translation)	RO	Instrucțiunile pentru utilizare (traducere)
ESP	Instrucciones de uso (traducción)	RU	Инструкция по эксплуатации (транслация)
FIN	Käyttöohjeet (käännös)	SK	Návod na použitie (preklad)
FR	Instructions d'utilisation (traduction)	SWE	Användarinstruktioner (translation)
GR	Οδηγίες χρήσης (μετάφραση)	TR	Kullanım talimatları (tercüme)
HR	Upute za korištenje (prijevod)	BG	Инструкции за Употреба (превод)
HU	Felhasználói kézikönyv (fordítás)	CN	使用说明(翻译)
IT	Istruzioni per l'uso (traduzione)	ARA	تعليمات الاستخدام (الترجمة)



PRODUCT SUPPORT LINK

<http://axagon.eu/produkty/hmc-5hl#supportLinkGoal>

- ENG** SuperSpeed USB hub with HDMI, GLAN, PD, USB-A ports
- CZ** SuperSpeed USB hub s HDMI, GLAN, PD, USB-A porty
- DE** SuperSpeed USB-Hub mit HDMI, GLAN, PD, USB-A Anschlüssen
- DK** SuperSpeed USB-hub med HDMI, GLAN, PD, USB-A porte
- ESP** Hub SuperSpeed USB con HDMI, GLAN, PD, puertos USB-A
- FIN** SuperSpeed USB-keskitin, jossa HDMI, GLAN, PD, USB-A-porttia
- FR** Hub SuperSpeed USB avec HDMI, GLAN, PD, ports USB-A
- GR** Hub SuperSpeed USB με HDMI, GLAN, PD, θύρες USB-A
- HR** SuperSpeed USB hub s HDMI, GLAN, PD, USB-A priključka
- HU** SuperSpeed USB hub HDMI, GLAN, PD, USB-A csatlófelülettel
- IT** Hub SuperSpeed USB con HDMI, GLAN, PD, porte USB-A
- NL** SuperSpeed USB-hub met HDMI, GLAN, PD, USB-A poorten
- PL** Hub SuperSpeed USB z HDMI, GLAN, PD, USB-A portami
- PT** Hub SuperSpeed USB com HDMI, GLAN, PD, USB-A portas
- RO** Hub SuperSpeed USB cu HDMI, GLAN, PD, porturi USB-A
- RU** SuperSpeed USB-концентратор с HDMI, GLAN, PD, USB-A портами
- SK** SuperSpeed USB hub se HDMI, GLAN, PD, USB-A portmi
- SWE** SuperSpeed USB hub med HDMI, GLAN, PD, USB-A portar
- TR** HDMI, GLAN, PD, USB-A bağlantı noktasına sahip SuperSpeed USB 5 Gbps hub
- BG** SuperSpeed USB хъб с HDMI, GLAN, PD, USB-A порта
- CN** 具有HDMI, GLAN, PD, USB-A端口的SuperSpeed USB 集线器
- ARA** SuperSpeed USB معHDMIوGLANوPDو أربعة منافذUSB-A

© 2023 AXAGON
Výrobce / Manufacturer: RealQ s.r.o. - Železná 5, 619 00 Brno, Czech Republic
All rights reserved. All text and pictorial materials contained in this document are protected by Copyright Act.
All marks indicated here are the registered trademarks of their appropriate owners. Specifications are subject to change without prior notice.
Made in CHINA for Axagon.



EN	CZ	DE	DK	ESP	FIN	FR	GR	HR	HU	IT	NL	PL	PT	RO
1. Turn on computer.	1. ZapnĚte počítaĉ.	1. Schalten Sie den Rechner ein.	1. Tænd for computeren.	1. Encienda el ordenador.	1. Kytke tietokone päälle.	1. Allumez l'ordinateur.	1. Aνοίξτε τον υπολογιστή.	1. Upalite računalo.	1. Kapcsolja be a számítógépet.	1. Accendete il computer.	1. Schakel de computer in.	1. Proszę włączyć komputer.	1. Ligue o computador.	1. Porniți PC-ul.
2. Connect the hub to the PC USB port.	2. Pripojte hub k USB portu PC.	2. Schließen Sie den Hub an den USB-Anschluss des PCs an.	2. Forbind hubben til Pc'ens USB port.	2. Conecte el hub al puerto USB de la PC.	2. Kytke keskitin tietokoneen USB-väylään.	2. Connectez le hub au port USB du PC.	2. Συνδέστε το καλώδιο USB στη θύρα USB του υπολογιστή.	2. Priključite hub na USB priključak računala.	2. Csatlakoztassa az hub-ot a PC USB portjához.	2. Collegare l'hub alla porta USB del PC.	2. Sluit de hub aan op de USB poort van de PC.	2. Podłącz hub do portu USB komputera PC.	2. Conecte o hub à porta USB do PC.	2. Conectați hub-ul la portul USB al PC-ului.
3. An automatic installation will be performed. No need to install any external drivers.	3. ProbĚhne automatická instalace. Nejsou potřeba žádné externí ovladaĉe.	3. Es erfolgt eine automatische Installation. Es sind keine externen Treiber notwendig.	3. En automatisk installation vil blive udført. Du behøver ikke installere eksterne drivere.	3. Se procede a la instalación automática. No es necesario instalar controladores externos adicionales.	3. Automaattinen asennus suoritetaan. Ulkoisia ajureita ei tarvitse asentaa.	3. L'installation aura automatiquement lieu. Aucun pilote externe n'est nécessaire.	3. Θα εκτελεστεί μια αυτόματη εγκατάσταση. Δεν χρειάζεται να εγκαταστήσετε εξωτερικούς.	3. Plzvršit će se automatska instalacija. Nije potrebno instalirati dodatne upravljaĉke programe.	3. Végbemegy az automatikus telepítés. Nem szükséges semmilyen külső vezérlő.	3. Ha luogo l'installazione automatica. Non è necessario nessun driver esterno.	3. Er wordt een automatische installatie uitgevoerd. U hoeft geen externe stuurprogramma's te installeren.	3. Urządzenie zostanie zainstalowane automatycznie. Nie są potrzebne żadne sterowniki zewnętrzne.	3. Será executada uma instalação automática. Não há necessidade de instalar drivers externos.	3. Rulează instalarea automată. Nu sunt necesare niciun fel de drivere externe.
4. The hub is ready.	4. Hub je připraven.	4. Der Hub ist bereit.	4. Hubben er klar.	4. El hub está listo.	4. Keskitin on valmis käytettäväksi.	4. Le hub est prêt.	4. Ο δίκος είναι έτοιμος για χρήση.	4. Hub je spreman.	4. A hub készen áll.	4. L'hub è pronto.	4. De hub is klaar.	4. Hub jest gotowy.	4. O hub está pronto.	4. Hub-ul este gata.

RU	SK	SWE	TR	BG	CN
1. Включить компьютер.	1. Zapnite počítaĉ.	1. Starta datorn.	1. Bilgisayarı açın.	1. Включете компютъра.	1. 打开电脑。
2. Подключите концентратор к USB-разъёму вашего компьютера.	2. Pripojte hub k USB portu PC.	2. Anslut hubben till datorns USB-port.	2. Çoklayıcıyı PC USB bağlantı noktasına bağlayın.	2. Свържете хъба към USB порта на компютъра.	2. 将集线器链接到个人计算机 (PC) USB端口。
3. Происходит автоматическая установка. Не требуется никаких внешних драйверов.	3. Prebehne automatická inštalácia. Nie sú potrebné žiadne externé ovládaĉe.	3. Automatisk installation sker. Inga drivrutiner behöver installeras.	3. Kurulum otomatik olarak başlayacaktır. Herhangi bir harici sürücü kurmanıza gerek yok.	3. Протича автоматична инсталиране. Няма нужда от никакви външни драйвери.	3. 此时将执行自动安装。 这一过程中无需安装任何外部驱动程序。
4. Концентратор готов к работе.	4. Hub je pripravený.	4. Hubben är klar.	4. Çoklayıcı hazır.	4. USB хъба е готов.	4. 集线器 (hub) 已经准备好了。

ARA

- قم بتشغيل الكمبيوتر.
- قم بتوصيل لوحة الوصل بمنفذ USB بالكمبيوتر.
- سيتم تنفيذ التثبيت التلقائي.
- لا حاجة لتثبيت أي برامج تشغيل خارجية.

TECHNICAL SPECIFICATIONS

INPUT INTERFACE: USB-C

- USB 3.2 Gen 1 (USB 3.0) • USB 2.0
- 5000 • 480 • 12 • 1.5 Mbit/s (Super • High • Full • Low Speed)
- USB-C male connector

OUTPUT INTERFACE: USB-A

- 2x USB 3.2 Gen 1 ports for data with USB-A female connectors
- up to 2 external disks can be connected at the same time
- up to 0.5 Amp charging on USB ports
- HDMI female connector
- Max. resolution 4K/60Hz (4096 x 2160 @ 60Hz)
- HDCP 1.4 a 2.3 (High-bandwidth Digital Content Protection) support
- TMDS (Transition Minimized Differential Signaling) support
- 8-CH LPCM audio - compress audio (AC-3, DTS) and HBR audio format support
- Up to 192kHz / 24bit — depends on source and target device parameters i.e. notebook/phone and TV/monitor/AV receiver

*Audio + Video function requires DisplayPort Alternate Mode (DP Alt Mode) or Thunderbolt 3 compatible port + OS support

LAN

- RJ-45 connector for UTP or STP cable
- Gigabit 10/100/1000 Mbit/s data rate
- IEEE 802.3 10Base-T
- IEEE 802.3u 100Base-TX
- IEEE 802.3ab 1000Base-T
- Microsoft NDIS5 / NDIS6 Checksum Offload (IPv4, IPv6, TCP, UDP) to reduce CPU loading
- Segmentation Task-offload Large Send V1 & Large Send V2
- IEEE 802.1P Layer 2 Priority Encoding
- IEEE 802.1Q VLAN tagging
- Full Duplex with IEEE 802.3x Flow Control
- Wake-on-LAN
- AMD Magic Packet or Microsoft Wakeup Frame
- Energy Efficient Ethernet (EEE)
- Microsoft Always On Always Connected (AOAC)
- Wake Packet Detection (WPD)
- Link Power Management (LPM)
- 'RealWoW!' (Wake-on-WAN) Technology
- Protocol Offload (ARP & NS)

Power Delivery 3.0

- USB-C female connector
- Notebook/phone charging through the hub
- Max power through the hub 100W (20V/5A)
- *requires device with PD power support and matching PD charger

OTHER FEATURES:

- Plug and Play & Hot Plug
- APPLE charging supported
- Power Delivery power / USB bus power - powered from PD charger or USB-C port

SIZE NET WEIGHT:

- 78 x 66 x 14 mm & 64 g
- Cable Length 15 cm

OS SUPPORTED:

- Windows 10 • 11, macOS, Linux, Android, Chrome OS
- * Updated OS required. Automatic driver installation — no driver needed. Correct PD and DP Alt Mode function depends on OS and device manufacturer support.



